

OPTION 3005

TRUE RMS INPUT.

- Factory fitted current or voltage input.
- Accuracy 0.5% at 50Hz.
- This is usually used for measuring mains voltage or current.
- Use the analogue input + and - terminals.



P O Box 418, Honeydew 2040 South Africa
21 Precision Street, Kyaland Randburg.
Telephone: +27 11 462-1920
Telefax: +27 11 462-1958
email: info@instrotech.co.za
web: www.instrotech.co.za

